

# 1000150



1. COFFEE POT.
2. POT LID.
3. RELEASE BUTTON.
4. HANDLE.
5. SPOUT.



## ⚠️ WARNINGS & PRECAUTIONS ⚠️

Use only as described in this User Guide.

Do not microwave or freeze.

Do not place the Coffee Pot on stoves.

Do not drop the Vacuum Coffee Pot as this can cause damage.

Keep the Vacuum Coffee Pot out of reach of children when filled with hot liquids.

Always hold the Coffee Pot using the handle as the Coffee Pot surface can become hot.

Take extra care when securing the lid as hot liquid or steam may escape from the spout.

Take care when using the Release Button. If the beverage is too hot when added, steam may build up and release in a short burst. Do not direct the spout towards people or animals.

Always check and make sure the lid is secured before pouring.

Do not use bleach or cleansers containing chlorine to clean.

This Vacuum Coffee Pot is not dishwasher-safe. Wash by hand only.

Always wash and dry the Vacuum Coffee Pot between uses.

Do not overfill. Hot liquid can cause scalding to the user.

## USAGE

- Before first use, check the Vacuum Coffee Pot for signs of damage. Do not use if the product is damaged.
- Wash the Vacuum Coffee Pot thoroughly using warm soapy water.
- Using a kettle, prepare your hot beverage i.e Tea or Coffee to add to the Coffee Pot. Allow the to cool slightly to a drinkable temperature before adding to the Coffee Pot.
- ⚠️ **WARNING!** Take extreme care when transferring hot beverage to the Coffee Pot.  
**IMPORTANT:** Do not exceed the Maximum capacity of 2 Litres.
- Screw the **POT LID** onto the Coffee Pot ensuring a secure fit. Always check the **POT LID** is correctly fitted before pouring your beverage.
- To pour, simply press and hold down the **RELEASE BUTTON**.
- NOTE:** When the **RELEASE BUTTON** is first pressed after adding your hot beverage, steam may escape from the **SPOUT**.
- This product is designed to keep liquids hot or cold for an extended amount of time.

# CLEANING & MAINTENANCE

---

- After use, discard of any remaining liquid and then add a few drops of detergent to the **POT** along with warm water. Screw on the **POT LID** and shake for several minutes.

**IMPORTANT:** Do not use bleach or chlorine based products as they are extremely corrosive to stainless steel, even when diluted. Only use mild detergent.

- Using a cleaning brush, scrub the inside of the **POT** and around the **POT LID** rim. Rinse with clean cold water.
- If there are any remaining tea or coffee stains, leave the **POT** to soak in warm soapy water and wipe with a sponge. Rinse and dry thoroughly.
- Discolouration can appear on the outer surface of the Coffee pot and can be removed with a special cleaner for stainless steel, or by adding lemon juice or vinegar to your regular cleaning solution.

**IMPORTANT:** Do not wash any part of the Vacuum Coffee Pot in the dishwasher. They are not dishwasher safe.

**IMPORTANT:** Avoid using abrasive scourers or scouring powders.

**TIP:** To eliminate any odours that may build up over time, mix a solution of 4 tablespoons/1oz of baking soda in 175ml/6 fl oz of warm water. Add the solution to the **POT**, apply the **POT LID** and leave to stand for 30 minutes or until the odour dissipates. Rinse well and dry.

# CUSTOMER SERVICES

---

If you are having difficulty using your product and require support, please contact [supoort@domu.co.uk](mailto:supoort@domu.co.uk)

# DISPOSAL INFORMATION

---

Please recycle where facilities exist. Check with your local authority for recycling advice.

# WARRANTY

---

To register your product and find out if you qualify for a free extended warranty, go to:

**[www.VonShef.com/warranty](http://www.VonShef.com/warranty)**

Please retain a proof of purchase receipt or statement as proof of the purchase date.

The warranty only applies if the product is used solely in the manner indicated in this manual and all instructions have been followed accurately. Any abuse of the product or the manner in which it is used will invalidate the warranty.

Returned goods will not be accepted unless re-packaged in its original packaging and accompanied by a relevant and completed returns form. This does not affect your statutory rights.

No rights are given under this warranty to a person acquiring this appliance second-hand or for commercial or communal use.

# COPYRIGHT

---

All material in this instruction manual are copyrighted by DOMU Brands Ltd.

Any unauthorised use may violate worldwide copyright, trademark, and other laws.

VonShef is a registered trademark of DOMU Brands Ltd  
Made in China for DOMU Brands Ltd M24 2RW.