

1000383



Please read all instructions carefully before use and retain for future reference.

Veillez lire attentivement ces instructions avant utilisation et conservez-les pour pouvoir les consulter à l'avenir.

Bitte lesen Sie die Anleitung sorgfältig und bewahren Sie sie als Referenz auf.

Leed todas las instrucciones detenidamente antes de usar y retened para futuras consultas.

Si prega di leggere attentamente tutte le istruzioni prima dell'uso e conservarle per una futura consultazione.



Materials approved for food use.

Matériaux approuvés pour un usage alimentaire.

Materialien sind für Lebensmittel zugelassen.

Materiales aprobados para uso alimentario.

Materiali approvati per uso alimentare.



Not suitable for oven use.

Ne peut pas être utilisé au four à microondes.

Nicht für die Mikrowelle geeignet.

No apto para uso en microondas.

Non adatto per microonde.



Not dishwasher safe.

Ne va pas au lave-vaisselle.

Nicht spülmaschinenfest.

No apto para lavavajillas.

Non lavabile in lavastoviglie.



EN

Please read all instructions carefully before use and retain for future reference.

INTENDED USE Only use the Pizza Paddle for its intended purpose and within the parameters specified in this manual.

This Paddle is for domestic use only. Do not use outdoors or on wet surfaces.

The Paddle is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless supervised or given appropriate instruction concerning the product's use by a person responsible for their safety.

BEFORE FIRST USE Before using your Pizza Paddle for the first time, remove all packaging, stickers and labels from the product and store or dispose of safely.

Wash thoroughly in warm, clean, soapy water with a soft cloth and mild detergent. Dry thoroughly using a clean, dry cloth or paper towel.

Never insert the Paddle Handle into the oven.

IMPORTANT! Ensure the locking nut is fully loosened to ensure the handle does not scratch the Stainless Steel Plate

GENERAL SAFETY

The Paddle is not suitable for use in a dishwasher.

The Paddle is not suitable for use in microwaves or ovens.

Do not subject the Paddle to sudden temperature changes as this will cause damage.

Sharp knocks, impact or dropping your Paddle can cause damage.

Do not use damaged Pizza Paddle.

Do not place a hot Pizza Paddle directly onto other surfaces.

Always use the Handle and a suitable heat-resistant mat.

Always use suitable heat-resistant oven gloves when handling the Pizza Paddle as it will become extremely hot during use.

CLEANING & MAINTENANCE

Do not immerse the Pizza Paddle in water as this will damage the wood handle.

Always wash after each use to minimise food stains.

The Pizza Paddle is prone to staining when exposed to acidic and oily foods or flames. Wash in warm, clean, soapy water with a mild detergent and soft sponge.

Do not use scented detergents as they can leave residue that can transfer onto food.

Do not use any metal, harsh abrasive or very stiff cleaning pads/washing up brushes, or abrasive cleaning agents on any of the surfaces.

Rinse well with warm water to remove any soap residue and dry thoroughly.

Loosen the locking nut and fold the handle to store.

IMPORTANT! Ensure the Locking Nut is not over-tightened as this will cause the handle to create indentations on the Stainless Steel Plate.



EN

DISPOSAL INFORMATION Please recycle where facilities exist. Check with your local authority for recycling advice.

CUSTOMER SERVICE If you are having difficulty using this product and require support, please contact support@domu.co.uk

WARRANTY To register your product and find out if you qualify for a free extended warranty please go to www.vonshef.com/warranty. Please retain a proof of purchase receipt or statement as proof of the purchase date. The warranty only applies if the product is used solely in the manner indicated in the warnings page of this manual, and all other instructions have been followed accurately. Any abuse of the product or the manner in which it is used will invalidate the warranty. Returned goods will not be accepted unless re-packaged in its original packaging and accompanied by a relevant and completed returns form. This does not affect your statutory rights. No rights are given under this warranty to a person acquiring the appliance second-hand or for commercial or communal use.

COPYRIGHT All material in this instruction manual are copyrighted by DOMU Brands. Any unauthorised use may violate worldwide copyright, trademark, and other laws.

THANK YOU

Thank you for purchasing your product/appliance.

Should you require further assistance with your purchase, you can contact us at

support@domu.co.uk

VonShef is a registered trademark of DOMU Brands Ltd.
Made in China for DOMU Brands. M24 2RW.