

1500048



Please read all instructions carefully before use and retain for future reference.

Veuillez lire attentivement ces instructions avant utilisation et conservez-les pour pouvoir les consulter à l'avenir.

Bitte lesen Sie die Anleitung sorgfältig und bewahren Sie sie als Referenz auf.

Leed todas las instrucciones detenidamente antes de usar y retened para futuras consultas.

Si prega di leggere attentamente tutte le istruzioni prima dell'uso e conservarle per una futura consultazione.



Not dishwasher safe.

Ne va pas au lave-vaisselle.

Nicht spülmaschinenfest.

No apto para lavavajillas.

Non lavabile in lavastoviglie.



Materials approved for food use.

Matériaux approuvés pour un usage alimentaire.

Materialien sind für Lebensmittel zugelassen.

Materiales aprobados para uso alimentario.

Materiali approvati per uso alimentare.



Not suitable for oven use.

Ne convient pas pour une utilisation au four.

Nicht für den Backofen geeignet.

No es adecuado para usar en el horno.

Non adatto per l'uso in forno.



Not suitable for microwave use.

Ne peut pas être utilisé au four à microondes.

Nicht für die Mikrowelle geeignet.

No apto para uso en microondas.

Non adatto per microonde.



EN

Please read all instructions carefully before use and retain for future reference.

INTENDED USE Only use the Fondue Set for its intended purpose and within the parameters specified in this manual. This Fondue Set is for domestic use only. Do not use outdoors or on wet surfaces.

The Fondue Set is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless supervised or given appropriate instruction concerning the product's use by a person responsible for their safety.

BEFORE FIRST USE Before using your Fondue Set for the first time, remove all packaging, stickers and labels from the product and store or dispose of safely.

Wash thoroughly in warm, clean, soapy water with a soft cloth and mild detergent. Dry thoroughly using a clean, dry cloth or paper towel.

RISK OF PERSONAL INJURY.

As the Fondue Pot Stand and Burner Dish/Plate will become hot during use, always place them on a suitable heatproof surface, such as a large tile or heat-resistant tray.

Certain oils used for cooking and fuels for burning have different smoking properties. Always ensure sufficient ventilation before use.

Take precautions to protect the set from winds or breezes which may cause the fuel to flash or spill.

Keep the product 1 metre away from flammable materials such as furniture, fabrics and any possible sources of ignition.

Keep hair and loose clothing away from the product at all times to prevent accident or injury.

Do not overfill the Fondue Set or Burner or add additional fuel to the Burner Dish whilst it is still lit or hot. The flame should be extinguished and the Burner Dish allowed to cool fully before adding additional fuel.

Always follow the guidance of the fuel manufacturer when handling or igniting any fuel.

Do not mix different fuel types. Dispose of used fuels in line with the fuel manufacturer's instructions. Never flush or pour fuel into drains.

Do not use a lighter. Use of a suitable burning taper or long match (not supplied) is recommended.

Do not tip the Burner Dish to ignite.

Clear any spilt fuel immediately. Close the flame off to extinguish and do not allow to evaporate. Clear fuel or spills using the methods recommended by the fuel manufacturer. Cap the Burner Dish with the Snuffer Lid and use the handle to close the holes in order to extinguish the flame. Exercise extreme caution around the Burner and fuel.

Do not allow the Fondue Set to burn whilst unattended. Open flames should be supervised at all times.

WARNING! The Fondue Set will become extremely hot during use and will remain hot for some time afterwards. Never handle the Fondue Set or Burner when in use. Always use suitable heat-resistant oven gloves to handle the Fondue Set when it has cooled down sufficiently. Handle with extreme caution so as not to not spill any food or fuel.

CAUTION: The supplied Fondue Forks are intended for food preparation only. To prevent the Fondue Set from becoming contaminated when in use, it is recommended that alternative cutlery is provided for guests to eat.

Do not lubricate any parts or carry out any maintenance or repair work other than that shown in this manual, or as advised by the DOMU Brands Customer Care Helpline.

CLEANING & MAINTENANCE Always wash after each use to minimise stains.

Do not use any metal, harsh abrasive or very stiff cleaning pads/washing up brushes, or abrasive cleaning agents on any of the surfaces. Stubborn stains can be removed by leaving the Fondue Set to soak in warm water and scrubbing gently using a suitable non-abrasive scouring pad. Rinse well with warm water to remove any soap residue and dry thoroughly with a clean cloth to prevent water stains from forming. Store in a cool, dry area out of reach of children.

WARNING! If the oil catches fire, smother with a lid or fireproof blanket. Never try to extinguish the flame with water.

CONTENTS



- 1. SWISS FONDUE POT.
- 2. FONDUE HANDLE.
- 3. FONDUE POT STAND.
- 4. FONDUE FORK (x6).

- 5. SNUFFER LID.
- 6. BURNER DISH.
- 7. BURNER PLATE.

BEFORE FIRST USE

Before using this appliance for the first time, please ensure you complete the following steps:

- Before first use, wash all components in hot soapy water with a mild detergent. Dry thoroughly immediately afterwards.
- Refer to the '**Cleaning & Maintenance**' section for guidance on how to clean the Fondue Set.

CAUTION: No parts of the Swiss Pot Fondue Set are suitable for use in a dishwasher. Always wash by hand.

OPERATION

- Place the **BURNER PLATE** onto a flat, stable, heat-resistant surface.
- Place the **BURNER DISH** firmly in the centre of the **BURNER PLATE** and add 80ml/3oz of suitable fuel into the **BURNER DISH**. Take some time to read the usage instructions supplied by the fuel manufacturer.

CAUTION: For fuels which burn with more intensity, use a lesser amount.

- Cap with the **SNUFFER LID** and open the holes by turning the handle. Carefully wipe away any fuel which has spilt. Do not ignite the fuel at this stage.
- Place the **FONDUE POT STAND** and **FONDUE POT** onto the **BURNER PLATE**, directly over the **BURNER DISH**.
- Fill the **FONDUE POT** with your chosen foodstuff (such as fondue cheese, chocolate or oil) and add the **FONDUE POT LID**.
- Using a suitable taper or long match, ignite the fuel by lighting through the holes in the side of the **BURNER DISH**. Control the flame by carefully turning the handle on the **SNUFFER LID**; opening the holes on the **SNUFFER LID** will increase the size of the flame, closing the holes will decrease the size of the flame and fully closing the **SNUFFER LID** holes will extinguish the flame.

CAUTION: Do not keep the Burner on maximum flame for extended periods to prevent scorching/burning.

- Allow the foodstuff inside the **FONDUE POT** to reach cooking temperature (variable depending on foodstuff). Remove the **FONDUE POT LID** using suitable heat-resistant oven gloves and insert dipping foodstuffs into the mixtures using the **FONDUE FORKS** to coat/cook as desired. Adjust the **SNUFFER LID** using the handle to maintain cooking temperature.

NOTE: Cooked/coated food should be transferred to a plate and eaten with separate cutlery to prevent contamination of the cooking pot.

CAUTION: Never cut food in the **FONDUE POT**.

- When finished, close all holes on the **SNUFFER LID** to extinguish the flames.



WARNING! Never handle the **BURNER** or **POT** when in use or directly after use. Allow to cool sufficiently to safely handle using suitable heat resistant oven gloves.

CLEANING & MAINTENANCE

CAUTION: Always allow the Fondue Set to cool fully before cleaning or storing.

- **DO NOT** plunge into, or fill with, cold water when hot.
- **ALWAYS** wash your Fondue Set after each use. Wash in warm, clean, soapy water with a mild detergent and soft sponge. Dry thoroughly afterwards.
- **DO NOT** use any metal, harsh abrasive or very stiff pads/washing up brushes, or abrasive cleaning agents on ANY of the surfaces.
- Stubborn stains can be removed using a suitable non-metallic scouring pad.

CAUTION: Your Fondue set is not suitable for use in a dishwasher.

- **DO NOT** use the Fondue Set to store food after use. Residue, salts, sugars and acids released by food can damage your Fondue Set.



EN

DISPOSAL INFORMATION Please recycle where facilities exist. Check with your local authority for recycling advice.

CUSTOMER SERVICE If you are having difficulty using this product and require support, please contact support@domu.co.uk

WARRANTY To register your product and find out if you qualify for a free extended warranty please go to www.vonshef.com/warranty. Please retain a proof of purchase receipt or statement as proof of the purchase date. The warranty only applies if the product is used solely in the manner indicated in the warnings page of this manual, and all other instructions have been followed accurately. Any abuse of the product or the manner in which it is used will invalidate the warranty. Returned goods will not be accepted unless re-packaged in its original packaging and accompanied by a relevant and completed returns form. This does not affect your statutory rights. No rights are given under this warranty to a person acquiring the appliance second-hand or for commercial or communal use.

COPYRIGHT All material in this instruction manual are copyrighted by DOMU Brands. Any unauthorised use may violate worldwide copyright, trademark, and other laws.

FR

INFORMATIONS RELATIVES AU RECYCLAGE

Veuillez recycler là où il existe des installations adéquates. Vérifiez auprès de vos autorités locales pour obtenir des conseils sur le recyclage.

SERVICE CLIENT Si vous rencontrez des difficultés pour utiliser ce produit et avez besoin d'assistance, veuillez contacter support@domu.co.uk

GARANTIE Pour enregistrer votre produit et découvrir si vous vous qualifiez pour une extension gratuite de garantie, rendez-vous sur www.vonshef.com/warranty. Conservez une preuve d'achat, reçu ou attestation, pour prouver la date de l'achat. La garantie ne s'applique que si le produit a été utilisé de la manière indiquée dans la section de la page des avertissements de ce manuel et que toutes les instructions ont été suivies de manière précise. Tous les abus réalisés sur le produit, dans la manière dont il a été utilisé, rendront la garantie caduque. Les marchandises renvoyées ne seront acceptées que si elles sont remballées dans leur emballage d'origine et accompagnées d'un formulaire de retour adéquat et rempli. Ceci n'affecte pas vos droits statutaires. Cette garantie n'accorde aucun droit à une personne obtenant le produit de seconde main ou à des fins d'utilisation commerciale ou communale.

DROITS D'AUTEUR Toutes les informations de ce manuel d'utilisation sont protégées par droit d'auteur par DOMU Brands. Toute utilisation non autorisée pourrait enfreindre les lois mondiales de droit d'auteur, de marque déposée ainsi que d'autres lois

DE

ENTSORGUNG Bitte entsorgen Sie das Produkt an geeigneten Entsorgungsstellen. Fragen Sie bei Ihrer Gemeinde nach.

KUNDENSERVICE Wenn Sie Schwierigkeiten mit diesem Produkt haben und Unterstützung benötigen, wenden Sie sich bitte an support@domu.co.uk

GARANTIE Um Ihr Produkt zu registrieren und zu erfahren, ob eine kostenlose verlängerte Garantie möglich ist, gehen Sie bitte auf www.vonshef.com/warranty. Bitte behalten Sie eine Rechnung oder den Kassenzettel als Nachweis des Einkaufsdatums auf. Die Garantie gilt nur, wenn das Produkt nur wie in dieser Anleitung beschrieben verwendet wurde und wenn alle Anweisungen befolgt wurden. Jeglicher Missbrauch des Produkts oder der Art und Weise, in der es verwendet wird, macht die Garantie ungültig. Zurückgegebene Artikel werden nur akzeptiert, wenn sie sich in der Originalverpackung befinden und wenn ein relevantes und vollständig ausgefülltes Rücksendeformular enthalten ist. Dies betrifft nicht Ihre gesetzlichen Ansprüche. Für Artikel, die gebraucht erworben wurden, oder die kommerzielle oder gemeinschaftlich genutzt werden, entstehen keinerlei Ansprüche auf Garantie.

COPYRIGHT Alle Materialien in dieser Anleitung stehen unter Copyright von DOMU Brands Ltd. Jede unautorisierte Verwendung kann das weltweite Copyright, die Handelsmarke und andere Gesetze verletzen.

ES

INFORMACION DE DESECHO Por favor, reciclad en las instalaciones correspondientes. Consultad con vuestra autoridad local para obtener consejos de reciclaje.

SERVICIO AL CLIENTE Si tiene dificultades para utilizar este producto y necesita asistencia, contacte con support@domu.co.uk

GARANTÍA Para registrar vuestro producto y averiguar si califica para una garantía extendida gratuita, vaya a www.vonshef.com/warranty. Conservad un comprobante de recibo de compra o extracto como prueba de la fecha de compra. La garantía solo se aplica si el producto se utiliza únicamente de la manera indicada en la página de advertencias de este manual, y todas las demás instrucciones se han seguido con precisión. Cualquier abuso del producto o la manera en que se use invalidará la garantía. Los productos devueltos no se aceptarán a menos que se vuelvan a empaquetar en su embalaje original y acompañados por un formulario de devolución completo y pertinente. Esto no afecta sus derechos legales. No se otorgan derechos bajo esta garantía a una persona que adquiere el aparato de segunda mano o para uso comercial o comunitario

DERECHOS DE AUTOR Todo el material en este manual de instrucciones está protegido por DOMU Brands. Cualquier uso no autorizado puede violar los derechos de autor, marcas comerciales y otras leyes en todo el mundo.

IT

INFORMAZIONI SULLO SMALTIMENTO Si prega di riciclare nelle apposite strutture. Chiedere una consulenza alle autorità competenti per il riciclo.

SERVIZIO CLIENTI Se si riscontrano difficoltà nell'utilizzo di questo prodotto e si richiede supporto, contattare support@domu.co.uk

GARANZIA Per registrare il prodotto e capire se hai diritto all'estensione di garanzia, vai su www.vonshef.com/warranty. Si prega di conservare la ricevuta del pagamento quale prova della data d'acquisto. La garanzia si applica solo se il prodotto viene utilizzato esclusivamente come indicato nella pagina delle Avvertenze del presente manuale e se tutte le altre informazioni vengano accuratamente seguite. Qualsiasi abuso nell'utilizzo di questo prodotto invaliderà la garanzia. I resi non saranno accettati se non riposti nella confezione originale ed accompagnati da un modulo di reso completo. Ciò non pregiudica i propri diritti obbligatori. La presente garanzia non attribuisce alcun diritto a coloro che acquistano prodotti di seconda mano o per fini commerciali o condivisi.

COPYRIGHT Tutto il materiale contenuto nel presente manuale delle istruzioni è protetto da copyright di DOMU Brands. Qualsiasi uso non autorizzato potrebbe violare il copyright a livello mondiale, marchio ed altre leggi.

THANK YOU

Thank you for purchasing your product/appliance.

Should you require further assistance with your

purchase, you can contact us at

support@domu.co.uk

VonShef is a registered trademark of DOMU Brands Ltd.

Made in China for DOMU Brands. M24 2RW.

MERCI

Merci d'avoir acheté notre produit/appareil.

Si vous aviez besoin d'aide suite à votre achat, vous pouvez nous contacter à

support@domu.co.uk

VonShef est une marque déposée de DOMU Brands Ltd.

Fabriquée en Chine pour DOMU Brands. M24 2RW.

VIELEN DANK

Vielen Dank, dass Sie das Produkt/Gerät gekauft

haben. Sollten Sie weitere Unterstützung benötigen,

können Sie uns gerne unter (email) kontaktieren.

support@domu.co.uk

VonShef ist eine registrierte Handelsmarke von DOMU Brands Ltd. Hergestellt in China für DOMU Brands.

M24 2RW.

GRACIAS

Gracias por comprar vuestro producto/aparato

Si requiere asistencia con vuestra compra, podeis con-

tactarnos a

support@domu.co.uk

VonShef es una marca registrada de DOMU Brands Ltd.

Hecha en China para DOMU Brands. M24 2RW.

GRAZIE

Grazie per aver acquistato il prodotto.

Per ulteriore assistenza sul tuo acquisto, puoi

contattarci all'indirizzo email

support@domu.co.uk

VonShef è un marchio registrato di DOMU Brands Ltd.

Made in Cina per DOMU Brands. M24 2RW.