

1507550



Please read all instructions carefully before use and retain for future reference.

Veuillez lire attentivement ces instructions avant utilisation et conservez-les pour pouvoir les consulter à l'avenir.

Bitte lesen Sie die Anleitung sorgfältig und bewahren Sie sie als Referenz auf.

Leed todas las instrucciones detenidamente antes de usar y retened para futuras consultas.

Si prega di leggere attentamente tutte le istruzioni prima dell'uso e conservarle per una futura consultazione.



Materials approved for food use.

Matériaux approuvés pour un usage alimentaire.

Materialien sind für Lebensmittel zugelassen.

Materiales aprobados para uso alimentario.

Materiali approvati per uso alimentare.



Dishwasher safe.

Lave-vaisselle.

Spülmaschinenfest.

Apto para lavavajillas.

Lavabile in lavastoviglie.



Not suitable for freezer use.

Ne convient pas pour une utilisation en congélateur.

Nicht für die Tiefkühlung geeignet.

No apto para uso en el congelador.

Non adatto per l'uso in congelatore.



EN

Please read all instructions carefully before use and retain for future reference.

INTENDED USE Only use the Plastic Storage/ Carry Box for its intended purpose and within the parameters specified in this manual.

This product is for domestic use only. Do not use outdoors or on wet surfaces.

The Storage/Carry Box is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless supervised or given appropriate instruction concerning the product's use by a person responsible for their safety.

This product is not suitable for hot beverages.

BEFORE FIRST USE Before using for the first time, remove all packaging, stickers and labels from the product and store or dispose of safely. Always check the product for any signs of damage before use. Do not use if damaged.

Wash thoroughly in warm, clean, soapy water with a soft cloth and mild detergent. Dry thoroughly using a clean, dry cloth or paper towel.

GENERAL SAFETY This Product is not suitable for use in microwaves, ovens or freezers. Unless stated otherwise at the point of sale.

Always ensure any lids are secure (where applicable). Do not invert.

CAUTION: The Storage/carry box are not heat-resistant. Exposing your items to high temperatures can cause permanent damage. Do not rest hot cookware on the Containers. Never place any of the Containers on a direct heat source such as a hob, open flame or any heating elements.

WARNING! DO NOT place the Storage/carry box inside microwaves or ovens.

Certain foods with strong colours or flavours can cause staining to the Storage/carry box that can be difficult to remove. Clean the Containers immediately after use, following the above guidelines, to preserve the finish.

Ensure the shelves and lid are securely locked into place before storing and carrying your food items.

DO NOT overload the boxes.

CLEANING & MAINTENANCE To remove any unpleasant stains and odours, make a thick paste of warm water and baking soda. Simply rub the mixture inside the Storage/carry box and allow to sit for at least a day. Rinse out thoroughly.



EN

DISPOSAL INFORMATION Please recycle where facilities exist. Check with your local authority for recycling advice.

CUSTOMER SERVICE If you are having difficulty using this product and require support, please contact support@domu.co.uk

WARRANTY To register your product and find out if you qualify for a free extended warranty please go to www.vonshef.com/warranty. Please retain a proof of purchase receipt or statement as proof of the purchase date. The warranty only applies if the product is used solely in the manner indicated in the warnings page of this manual, and all other instructions have been followed accurately. Any abuse of the product or the manner in which it is used will invalidate the warranty. Returned goods will not be accepted unless re-packaged in its original packaging and accompanied by a relevant and completed returns form. This does not affect your statutory rights. No rights are given under this warranty to a person acquiring the appliance second-hand or for commercial or communal use.

COPYRIGHT All material in this instruction manual are copyrighted by DOMU Brands. Any unauthorised use may violate worldwide copyright, trademark, and other laws.

THANK YOU

Thank you for purchasing your product/appliance. Should you require further assistance with your purchase, you can contact us at

support@domu.co.uk

VonShef is a registered trademark of DOMU Brands Ltd. Made in China for DOMU Brands. M24 2RW.