

# CUPCAKE STORAGE & CARRIER

# VonShef®

07/214 07/550 07/551

## - CARE GUIDE

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE REFERENCE.

## BEFORE FIRST USE

---

Before using your Storage/carry box for the first time, remove all packaging, stickers and labels from the product and retain for future reference or store for future use.

Hand-wash all items thoroughly in warm water with a mild detergent and dry thoroughly.

**CAUTION:** Do not use harsh or abrasive chemical cleaners or detergents with your Storage/carry box as this may cause damage or the quality to deteriorate. Use of metal scouring pads or similar is not recommended as this may also damage the finish.

## CLEANING & AFTER USE

---

The Storage/carry box are **top shelf** dishwasher-safe. It is, however, recommended to wash by hand in order to protect the product. Wash in warm soapy water with mild detergent and gently scrub using a soft sponge.

**TIP:** To remove any unpleasant stains and odours, make a thick paste of warm water and baking soda. Simply rub the mixture inside the Storage/carry box and allow to sit for at least a day. Rinse out thoroughly.

Store the Storage/carry box in a cool dry area without the lid attached.



## IMPORTANT CARE & USE

---

**CAUTION:** The Storage/carry box are **not** heat-resistant. Exposing your items to high temperatures can cause permanent damage. Do not rest hot cookware on the Containers. Never place any of the Containers on a direct heat source such as a hob, open flame or any heating elements.

**WARNING! DO NOT** place the Storage/carry box inside microwaves or ovens.

Certain foods with strong colours or flavours can cause stainage to the Storage/carry box that can be difficult to remove. Clean the Containers immediately after use, following the above guidelines, to preserve the finish.

Ensure the shelves and lid are securely locked into place before storing and carrying your food items.

**DO NOT** overload the boxes.

# CUSTOMER SERVICES

---

If, for any reason, this product proves to be unsatisfactory, please contact [hello@domu.co.uk](mailto:hello@domu.co.uk) or [usasupport@domubrand.com](mailto:usasupport@domubrand.com) as appropriate.

# DISPOSAL INFORMATION

---

Please recycle where facilities exist. Check with your local authority for recycling advice.

# WARRANTY

---

To register your product and find out if you qualify for a free extended warranty, go to:

[www.VonShef.com/warranty](http://www.VonShef.com/warranty)

Please retain a proof of purchase receipt or statement as proof of the purchase date.

The warranty only applies if the product is used solely in the manner indicated in this Care Guide and all instructions have been followed accurately. Any abuse of the product or the manner in which it is used will invalidate the warranty.

Returned goods will not be accepted unless re-packaged in its original packaging and accompanied by a relevant and completed returns form. This does not affect your statutory rights.

No rights are given under this warranty to a person acquiring this product second-hand or for commercial or communal use.

# COPYRIGHT

---

All material in this instruction manual are copyrighted by DOMU Brands Ltd.

Any unauthorised use may violate worldwide copyright, trademark, and other laws.

Thank you for purchasing the Cupcake Storage & Carrier.

VonShef® is a registered trademark of DOMU Brands Ltd  
Made in China for DOMU Brands Ltd M24 2RW.